

FACT SHEET

milKit – tubeless made easy

ADVANTAGES

- **Simple:** No air escapes from the tire while revolutionary rubber flaps seal the bottom of the valve. This means: no rush when inflating the tire
- **Clean:** No more valve clogging and no mess on you or your tire
- **Safe:** milKit compact shows exactly how much sealant is left in the tire – increasing puncture protection
- **Quick:** Check the sealant in the tire with milKit through the valve – no deflating and dismantling of the tire

USAGE

1. Screw off the milKit valve core: no air is lost (recommended pressure 1.5-22 psi)
2. Insert the milKit applicator tube through the valve into the tire and let the sealant run into the syringe. Make sure to close the stopcock as soon as all sealant is taken out of the tire.
3. Check the sealant's quantity and quality
4. Inject new sealant with the milKit applicator through the valve
5. Put back the valve core and go ride

PRODUCTS

milKit compact 35 / 55 / 75

Scope of supply: 1x measuring and refilling syringe, 2x milKit aluminum tubeless valves (35 mm, 55 mm or 75 mm), 1x applicator tube, 1x flexible extension with stopcock, 1x valve core tool, 1x manual

Recommended price:
from 55.95 €, 56.95 \$ or 49.95 £

milKit valve pack 35 / 55 / 75

Scope of supply: 2x milKit aluminum tubeless valves (35 mm, 55 mm or 75 mm), 1x valve core tool

Recommended price:
from 29.95 €, 29.95 \$ or 26.95 £

Where to buy:
www.milKit.bike/shop

